

Home Phone Replacement ACTIVATION INSTRUCTIONS

IMPORTANT - It's possible to damage your HPR device if it is not setup properly. To work correctly, your legacy telephone service must be disconnected. Even if you aren't paying for or using service, it's possible the signal is still active. The following instruction include how to test if this is this case. If you need to, purchase a tester at your local hardware store.

A. SETUP & TEST

1. Install antenna, power cord, then battery into HPR device. Do not plug into electrical outlet.
2. Test your home's telephone jack by plugging in a telephone line tester.
3. If the signal is active, proceed to "B". If it isn't, skip to "C".

B. DISCONNECTING OUTSIDE PHONE LINE

If the tester showed active signal, that means your legacy telephone service has not been disconnected. You can disconnect it yourself with the following steps.

1. Locate the telephone box outside your home.



2. Open the box and disconnect all phone jacks. In older homes, you may have to disconnect copper wires via a push plate.
3. Back inside, test telephone jack again. If there is no signal, proceed to "C".
4. Contact your old phone provider if you have any problems.

C. ACTIVATION

1. Plug HPR device into telephone jack and power outlet.
2. Hold power button and wait for screen to turn on.
3. Dial *28895. Listen for one ring-back tone and 15 seconds of white noise.
4. It will say "Activation Successful." Device will restart.
5. After disconnect tone, hang up and make test call using handset.
6. You can now use up to 5 phones through wall jacks around your home.

For additional help, see your device booklet.